

SanRex

Thyristor Type Power Adjusting Unit

CALPOTE

UF series

RS485 communication unit

UF - RS485

INSTRUCTION MANUAL

TABLE OF CONTENTS

FORWARD	2
1. PRECAUTIONS BEFORE USE	3
1.1 Confirmation of the product	3
1.2 The thing which has prepare	3
1.3 Attention in the use	5
1.4 How to install UF-RS485	5
2. TO CONNECT TO UF-RS485	6
3. HOW TO SET THE UF-RS485	7
3.1 How to set S3	7
4. HOW TO SETTING THE SET VALUES FROM UF-RS485	8
4.1 How to set the UF-RS485	8
5. COMPUTER AND HOW TO COMMUNICATE WITH THE UF-RS485	9

Attachment

RS-485 communication unit UF-RS485 MULTI-DROP METHOD USER MANUAL

FORWARD

Thank you very much for having purchased the "RS-485 communication unit UF-RS485 for Thyristor Type Power Adjusting Unit **UF series**".

The operators and other persons concerned are all requested to read this Operating Manual thoroughly and to operate this conversion board as instructed therein so that it can fulfill its functions perfectly.

Keep this Operating Manual carefully at any easily accessible place so that it can be referred to at any time when required.

In the following explanation, the RS-485 communication unit will abbreviate it to "UF-RS485".

1. PRECAUTIONS BEFORE USE

1.1 Confirmation of the product

Check if the following items are all provided.

- o UF-RS485 1unit
- o Screw for UF-RS485 installation 1pcs

1.2 The thing which has prepare

(1) RS485 cable

- ① Cable The twisted pair shield line which is higher than 10 cores
 Characteristic impedance 80Ω (at 1MHz)
 150Ω (at 10kHz)

Recommended

SPMC-10DG 10 cores made by Kaneko Code

② Connection connector

Plug D s u b 9pin

Recommended

XM2A-0901 made by Omron


Plug case D s u b 9pin

Recommended

XM2S-0911 made by Omron

※RS485 Cable for the UF-RS485, please prepare one per.

③ Wiring method



However, the portion of the cable shield, please plug connected to the case.

1-pin and 6-pin, 2-pin and 7-pin, please use the twisted pair.

※The cable is connected to the PLC power supply (Vcc, GND) wires do not need to.

(2) Connector termination

① Connection resistance

(A) Terminating resistance

(a) resistance $1/4 W \ 150 \ \Omega$

(b) Between 2-7 and 1-6 while the plug, please connect a resistor as shown below.

(B) Pull-up resistor, pull-down resistor

UF can be connected to the receiver communication unit, receiving the signal level is stable.

(a) Resistance $1/4 W$

Resistance, please see below.

Resistance is connected to a communication unit with a voltage change value.


Case of DC 9V power supply	$1.00 \text{ k}\Omega \leq R \leq 3.30 \text{ k}\Omega$
Case of DC 12V power supply	$1.00 \text{ k}\Omega \leq R \leq 4.43 \text{ k}\Omega$
Case of DC 15V power supply	$1.00 \text{ k}\Omega \leq R \leq 5.55 \text{ k}\Omega$
Case of DC 18V power supply	$1.01 \text{ k}\Omega \leq R \leq 6.68 \text{ k}\Omega$
Case of DC 24V power supply	$1.80 \text{ k}\Omega \leq R \leq 8.93 \text{ k}\Omega$


(b) Between 7-8 and 2-5 while the plug, please connect a resistor as shown below.

② Connection connector

Plug D s u b 9 pin
Recommended
XM2A-0901 made by Omron

Plug case D s u b 9 pin
Recommended
XM2A-0901 made by Omron



 : Terminating resistance

 : Pull-up resistor, pull-down resistor

1. 3 Attention in the use

- (1) While spend power switch, please do not do the exclusion and adding of the cable.
- (2) When UF-RS485 cable for connecting the connector insert and body, please insert to fit the grooves.
- (3) RS485 cable, the total wire length is 200m or less please.
- (4) Operation from UF-RS485 is made possible when the GT and PH on the terminal block of the unit are short-circuited.

However, the signal sent from the terminal block (ST terminal) is given priority.
In other words, operation cannot be stopped from UF-RS485 when ST and PH are short-circuited.

Additionally, even when the unit is operated from UF-RS485 , if the ST and PH are short-circuited and then opened, the unit stops operation.

1. 4 How to install UF-RS485

- (1) UF-unit has a cover for a communication connection is located on the side of the cut in the nippers etc. (Fig. 1. 4 (1))
- (2) UF-RS485 wires are connected, UF-unit connects. (Fig. 1. 4 (2))
- (3) UF-RS485 hooked to process it into two, UF-unit Connect. (Fig. 1. 4 (3))
- (4) The UF-unit and the UF-RS485, UF-RS485 using a secure mounting screws are included. (Fig. 1. 4 (4))




Fig. 1. 4 (1)




Fig. 1. 4 (2)




Fig. 1. 4 (3)





Fig. 1. 4 (4)

2. TO CONNECT TO UF-RS485



The UF-unit assumes 15 of them one group, and the connection of the UF-unit in the group is random order.


Please attach the terminal connector to "OUT" of UF-RS485 of the last unit of 15 UF-units. In addition, please be attached to "OUT" of UF-RS485 of the last unit when am less than 15.

3. HOW TO SET THE UF-RS485

UF-unit take the front cover, inside it has S3. If use the UF-RS485, S3 must be set.

3.1 How to set S3

In S3, UF-RS485 unit No. can be set.
S3 default has been set as follows.



Using the S3 1 - 4, UF-RS485 of UF-unit No. Set.
How to set S3, please take a look at the table below.

No.	S 3 - 1	S 3 - 2	S 3 - 3	S 3 - 4
0 (Not Set)	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON
15	ON	ON	ON	ON

4. HOW TO SETTING THE SET VALUES FROM UF-RS485

If set the UF-RS485, the signal display panel priority settings "2" should be set to change.

4.1 How to set the UF-RS485

Example

At the UF-RS485, L (Lower point(lower limit)signal) to be able to change settings.

- (1) If the [MODE] key is pressed while the [FUNC] key is being pressed down, the display mode is switched. Press several times, the display-mode of display panels show "INPUT". (Fig. 4.1 (1))




Fig. 4.1 (1)

- (2) Press the [SEL] key twice, 4-digit display on the left is "L" the display. (Fig. 4.1 (1))

- (3) If the [FUNC] key is pressed while the [SEL] key is being pressed down, the display mode is switched. The panels display by pressing the [FUNC] + [SEL] key one times to a 4-digit display on the left the "LS". (Fig. 4.1 (2))




Fig. 4.1 (2)

- (4) Press [▲] several times "2" the display panel. (Fig. 4.1 (2))
- (5) Numeric display will blink, [ENTER] key press and light the key once. (Fig. 4.1 (2))

Priority settings changed by manipulating the signal display panel as an example, UF-RS485 signals can change the settings

Table 1, by changing the settings on the display panel signal priority, UF-RS485 can change the signal settings.

Display item	Function
P	Control signal
H	Manual(upper limit) signal
L	Lower point(lower limit)signal
F	Grade signal
E	Soft start time
C	Current limit
U	Heater disconnecting amount
d	Delay time
—	Period time

Table 1

5. COMPUTER AND HOW TO COMMUNICATE WITH THE UF-RS485

The personal computer to communicate with the UF-RS485, refer to the attached document, please create programs.

Attachment

RS-485 communication unit UF-RS485 MULTI-DROP METHOD USER MANUAL

MEMO

 **SANSHA ELECTRIC MFG. CO.,LTD.**

Head Office

3-1-56 Nishiawaji, Higashiyodogawa-ku, Osaka
533-0031, Japan
Tel: 06-6325-0500 Fax: 06-6321-0355
<http://www.sansha.co.jp/>

SANREX CORPORATION (U.S.A)

50 Seaview Boulevard Port Washington, NY 11050-4618,
U.S.A
Tel: +1-516-625-1313 Fax: +1-516-625-8845

SANREX EUROPE GmbH (Germany)

Knorrstrasse 142, Munich D-80937, Germany.
Tel: +49-89-311-2034 Fax: +49-89-316-1636

SANREX LIMITED (Hong Kong)

Room 307, Kowloon Plaza, 485 Castle Peak Rd.,
Kowloon, Hong Kong
Tel: +852-2744-1310, +852-2785-6313
Fax: +852-2785-6009

SANREX ASIA PACIFIC PTE.LTD. (Singapore)

25, Tagore Lane, #04-02B Singapore Godown, 787602
Singapore
Tel: +65-6457-8867, +65-6459-6426 Fax: +65-6459-6425

FOSHAN CITY SHUNDE SANREX LIMITED (China)

Dazhou Shiliang Road Lunjiao Town, Shunde District,
Foshan City, Guangdong Province 528308 P.R.China
Tel: +86-757-2733-3688 Fax: +86-757-2783-3547

**SANSHA ELECTRIC MFG. (SHANGHAI) CO.,LTD
(China)**

Room 310, 555 Building, 555 West Nanjing Road,
Shanghai 200041, P.R. China
Tel: +86-21-5868-1058 Fax: +86-21-5868-1056

The specifications of this product described in this INSTRUCTION MANUAL may, incident
to any improvement in the product, be subject any change without prior notice.

K00A0087400 2011. 05. 26